

4.2 USB DRIVER INSTALLATION – WINDOWS OS

USB driver is required for Windows Operating System (Windows 7/8/8.1/10, X86/X64). The USB driver is licensed by THESYCON to provide the highest quality audio playback for Computer Audio System.

NOTE: Mac and Linux OS do not require the USB driver.

Installation Guide:

- Download the driver from the support page: <https://www.denafrips.com/support>
- Do not connect the USB cable from the computer to the DAC. Remove it before the USB driver installation
- Double click the “DENAFRIPS_UsbAudio_v4.82.0” to install the USB driver.
- Follow the on-screen instruction to complete the installation




Figure 4. Welcome screen




Figure 5. Default Installation Directory




Figure 6. Preinstallation Successful




Figure 7. Completed

- Restart the computer to complete the installation
- Connect the USB cable to the DAC
- Power on the DAC. Select USB input
- The USB DAC shall be detected. The driver status can be monitored as follows








Figure 8. Taskbar & Control Panel

- Select DENAFRIPS USB DAC as default Windows OS Soundcard

	
<p>Press Set Default button</p>	<p>Properties of the DENAFRIPS USB DAC</p>
	
<p>Direct-Sound default format</p>	<p>ASIO Buffer Size</p>

Playback software recommendation:

- roon
- JRiver
- Foobar2000
- Sonicstudio Amarra